

# Manual Supplement

Manual Title:	87V MAX Users Manual	Supplement Issue:	1
Part Number:	Web-Only	Issue Date:	10/21
Print Date:	October 2019	Page Count:	2
Revision/Date:	1, 2/20		

---

This supplement contains information necessary to ensure the accuracy of the above manual.

© 2021 Fluke Corporation. All rights reserved.



Autorisierter Distributor

**FLUKE®**

## Change #1, 653

On page 42, replace the value in the **Accuracy** column of the table under *AC Current* as shown here:

### AC Current

Function	Range	Resolution	Burden Voltage	Accuracy <sup>[1]</sup> (45 Hz to 2 kHz)
<b>μA ac</b>	600.0 μA	0.1 μA	100 μV/μA	±(1.0 % + 2)
	6000 μA	1 μA	100 μV/μA	
<b>mA ac</b>	60.00 mA	0.01 mA	1.8 mV/mA	
	400.0 mA <sup>[2]</sup>	0.1 mA	1.8 mV/mA	
<b>A ac</b>	6.000 A	0.001 A	0.03 V/A	
	10.00 A <sup>[3,4]</sup>	0.01 A	0.03 V/A	

[1] AC conversions are ac coupled, true rms responding, and valid from 3 % to 100 % of range, except 400 mA range (5 % to 100 % of range) and 10 A range (15 % to 100 % of range).

[2] 400 mA continuous. 600 mA for 18 hr maximum.

[3] W 10 A continuous up to 35 °C. <20 minutes on, 5 minutes off at 35 °C to 55 °C. >10 A to 20 A for 30 seconds maximum, 5 minutes off.

[4] >10 A accuracy unspecified.

## Change #2, a209

On pages 33 and 34, under *How to Replace the Batteries*, in step 2 and step 6, change “Phillips-head screws” to “Torx-head screws.”